

GROUP	MODEL
Electrical	2021MY Seltos (SP2)
NUMBER	DATE
PS653	March 2020



SUBJECT:

## VEHICLE AUTO-SHUT OFF SYSTEM

Some 2021MY Seltos (SP2) models are equipped with a new Auto-Shut Off feature, which automatically shuts off the engine after a set time period. This feature will help reduce fuel consumption and prevent carbon monoxide (CO) poisoning.

For the Auto-Shut Off feature to be activated, the vehicle must meet certain prerequisites conditions.

## Prerequisite Conditions

- 1. Ignition ON and engine running
- 2. Transmission is in the P (Park) position
- 3. The driver's seat belt is unfastened
- 4. The driver's door is opened
- 5. The passenger seat is not occupied

## Auto-Shut Off Settings

The driver may set the vehicle's shut-off timer to 60 min., 30 min.,  $\underline{or}$  Disable. Depending on the model, the settings can be changed by way of the instrument cluster display (User Settings  $\rightarrow$  Convenience) or the (AVN) head unit, if equipped.

## \* NOTICE

The default setting will be retained until the timer is reset. The timer will revert back to the previous setting at the next startup even if the driver had previously selected 'Disable' in the User Settings mode.